

110.00 mm

封面

VOCAL-STAR

UHF Wireless Microphone

INSTRUCTIONS

VS-HS

PRODUCT SUPPORT: INFO@VOCAL-STAR.COM

WWW.VOCAL-STAR.COM

80.00 mm

1. PRODUCT OVERVIEW

This product is a wireless audio transmitter and receiving device. The receiver has an optional mono and dual channel output. It can be connected to some mobile phones using the conversion plug to achieve recording and amplification functions. It can also support some SLR camera recording and amplification functions.

2. PRODUCT DETAILS

Figure 1: Transmitter

1. Volume-/Press for 3 seconds to convert frequency

2. Volume +/ Press for 10 seconds to pair

3. Power On/Off

4. Charging port (DC 5V=)

5. Working status indicator light (Blue light)

Charging indicator light (Red)

Figure 2: Receiver

1. 3.5mm-2 section of output plug

2. Working status indicator light (Blue light)

3. Charging indicator light (Red)

4. Power On/Off

5. Charging port (DC 5V=)

3. PRODUCT CONNECTION GUIDE

Push Rod Speakers
6.35mm(MIC) Port

Power Amplifier
6.35mm(MIC) Port

Loudspeaker
3.5mm(MIC) Port

Receiver

Conversion plug
(3.5mm To 6.35mm)

4. HOW TO USE

Please note: This should connect automatically when the power is on both the headset and receiver. If it disconnects, please manually pair the device.

CONNECTING RECEIVER AND TRANSMITTER

Switch on the transmitter, then press and hold the "+" key until the blue light flashes, then release it. Press the power button on the receiver for one second to turn on and enter wireless pairing.

Wait a few seconds and the blue light will light up. This indicates the pairing is successful and the product can be used.

FREQUENCY CONVERSION

After connecting the transmitter and receiver successfully, press "-" key on the transmitter for 3 seconds. The blue light will flash 5 times and enter into the frequency conversion mode. It will automatically reconnect after a few seconds. Frequency conversion is successful.

USE OF MULTIPLE CHANNELS

You can use up to 40 sets with no interference. When using multiple units simultaneously, they must be connected using the above steps. For example if using 10 transmitters "-" 1 time for the first transmitter, press "-" twice for the second transmitter and so on until you press "-" ten times for the tenth transmitter. You will need to use one receiver per transmitter.

LOW BATTERY

When the battery is low, the blue power indicator light will flash.

FACTORY RESET SETTINGS

Press and hold the volume + button to turn on power switch on the transmitter and release it once it starts flashing. Immediately press the power on button on the receiver. The blue light of the receiver will remain on for a few seconds. The reset is successful.

5. PRODUCT IMAGES

Headset

Transmitter

Receiver

3.5To6.35mm Conversion plug

USB Charging Cable

Note: The images are for reference only.

6. PRODUCT TECHNICAL INFORMATION

Frequency range:	550.5MHz-589.5MHz
Frequency Response:	50Hz-8KHz
Transmitting power:	15dBm
Receiving sensitivity:	≤-106dBm
Distortion:	< 1%(1KHz)
Operating frequency point:	40 Frequency Points
Battery	3.7V 400mAh

7. OPTIMUM POSITION FOR USE

Headset Microphone

Headset Microphone

About 1-1.5cm

8. NOTES AND TIPS

1. Recharge when the blue light flashes quickly to indicate low battery.

2. Do not block the transmitter or receiver. This will ensure there is no signal interruption.

3. Please do not try to take apart or repair. Please contact customer services or an qualified electrician.

4. Ensure not parts of the product come into contact with water, or are used in a damp environment.

5. Please keep the microphone away from speakers and other devices when in use.

6. If there is low sound, please check the volumes are up and the batteries not low.

7. If the volume is too high, please move the mouth piece away from the mouth.

8. If there is interference, please ensure the microphone is not too close to the mouth. Also do not use too close to speakers.

VOCAL-STAR

1 YEAR WARRANTY REGISTRATION REQUIRED

TO REGISTER - VISIT

vocal-star.com/warranty-registration

WARRANTY INFORMATION

All products have a six month warranty as standard. Registration is required to extend this to twelve months. Be sure to register for the additional six months by visiting the link below and completing the form. You will be sent a reply immediately with the warranty reference number. Be sure to keep this safe - as it will be required when making a claim. Register within 30 days of purchase. Please note cables, leads, remotes, CDs and microphones are not covered under warranty.

TO REGISTER - VISIT

vocal-star.com/warranty-registration