# VUCAL-STAR



# **USER MANUAL**

**MODEL: VS-355BT** 

- Before use, please read this manual carefully-

#### I Featur

- Ultra-large magnetic circuit high-sensitivity speaker with high penetrating power,low-frequency shock and perfect medium-/high-frequency representation.
- 2. The latest decoding chips supporting stably playback of MP3 in up to 32GB USB/TF card.
- FM radio reception high-quality digital radio with automatic channel search and storage of up to 30 channels.
- 4. 3. 5mm AUX audio input for each connection to a wide range of sound sources.
- 5. Built-in high-capacity battery for consecutive playback of up to 4 hours.
- Connect the microphone, adjustable reverberation, voice and Karaoke function to present outstanding performance.
- 7. Battery with built-in recharging protection to present a long and stable service life.
- 8. Built-in low battery and full recharging indication
- With handle for easy transportation.
- 10. Microphone input with vocal recording.
- 11. With Bluetooth function.

### II. Recording

#### Recording via External Microphone:


Connect a storage device (USB/TF card) and short press RECORD key to start recording for a time depending on the storage capacity. During recording, tune the "-ECHO+" knob to the minimum. It is noticeable that the microphone should be located a proper distance away from the speaker to prevent any howl-round or noise.

Notes: This product starts recording from the time as displayed on the LED screen.

## III. The bluetooth pairing operation and related parameters:

- 1.Power: switch the power to ON, press the key "MODE" to enter the mode of Bluetooth, the display screen will show "BLUE".
- 2.Switch on the Bluetooth function of Mobile phone and searching, while the Mobile phone shows "VS-355BT", click the connect directly. mobile phone connection do not need password, if need password, please input"0000" to go on pairing. After success pairing, the speaker will send out a prompt, it is success pairing between mobile phone and Bluetooth speaker.
- 3.Play Music from your Phone Tablet Laptop or any other Bluetooth source.Remember to turn up the volume on your Phone/Tablet aswell as adjusting on the speaker.

### IV. Functional Operations and Features



- LED Screen.
- Master Volume: In USB/TF Card/AUX in/FM/Bluetooth mode, use it to regulate volume output from the speaker.
- 3. TF Port: Read audio files in MP3 format in TF card in capacity up to 32G (FAT32).
- 4. USB Port: Read audio files in MP3 format in USB storage device in capacity up to 32G (FAT32)
- 5. I←: In the play status of USB/TF Card/Bluetooth, short press it to select the previous channel. In FM receiving status, short press it to select the previous channel after a full station search has been executed
- 6. In JCAN: In USB/TF card reading status, short press it to play/pause, or long press it to select one of two playback sequencing modes (All play all tracks in sequence; ONE repeat one track). In FM receiving status, long press it to execute a full search (it is recommended to execute at least one full search before using radio receiving function. All founded stations will be saved even in power-off). In Bluetooth reading status, short press it to play/pause, In AUX input / FM radio status, short press it to toggle between mute and normal volume.
- 7. ▶I: In USB/TF card/Bluetooth reading status, short press it to go to the next song. In FM receiving status, short press it to select the next channel after a full station search has been executed.
- 8. MODE/SHIFT/TWS: Short press it to toggle between USB/TF/AUX IN/Bluetooth and FM receiving modes. long press it to toggle between recording folder and MP3 folder; TWS interconnection mode: open the two machines that need interconnection at the same time, and switch to bluetooth mode at the same time. Pair one of them with the mobile phone's bluetooth to play music.Long press the play/pause button on the connected machine to exit the connected mode.

Long press the connected machine to the phone to exit the connected mode directly.

- ECHO: short press it is Microphone reverberation control button.
- 10. Recording/DEL: Short press it to enable recording. Durin recording, reverberation (Echo)should be tuned to the minimum. Long press it to delete a recording file. Recording in Microphone mode is available.
- EQ: In USB/TF/AUX/Bluetooth reading status short press it to select different sound modes (from NOR, POP,ROC,JAZ,CLA,CVB).
- 12. The :Short press it is light mode button.
- 13. Microphone volume: Microphone volume regulating knob.
- 14. Power: Power switch.
- 15. DC 5V recharging: DC 5V recharging port.
- 16. Recharging indicator light: When recharger is connected, the red light turns on. When the device is fully recharged, the blue light turns on.
- 17. AUX IN: External sound source input port (plug-and-play).
- 18. Microphone input: Microphone input jack.

For any other assistance please contact Vocal-Star www.vocal-star.com or Tel: 01202 670929